



# PlumbMaster, Inc.



## NEW PRODUCT

### WATCO NuFIT® LIFT & TURN TUB TRIM KIT

**ELIMINATES THE NEED TO REMOVE OLD STRAINER BODIES**

- Fits Into All Existing Strainer Bodies with Either a 3/8" or 5/16" Threaded Hole in the Cross Bars
- The New Lift & Turn Stopper is Screwed Into the Cross Bars of the Old Strainer Body
- Kit Includes Overflow Plate with Screw, Adapter Bar, Body with Lift & Turn Stopper and Silicone Adhesive Packet
- Chrome Plated
- OEM Ref. No. 48400CP

Cat. No. 37642



**Watco Manufacturing Company**  
Always a step ahead.



1. Remove the stopper from the old strainer body in the tub. Leave the old strainer body in the tub and place silicone adhesive on the flange.



2. Place the NuFit body into the old strainer body pressing the covering flange down onto the adhesive.



3. The NuFit body, with its bright new finish, is now securely in place ready for the new stopper.



4. Install new stopper and overflow plate.

Phone: 1-800-523-5130 • Fax: 1-800-338-1867 • [www.plumbmaster.com](http://www.plumbmaster.com)